






20a



















Deposit first kind of solder paste


Fig 11




Reflow wafer to form solder bump Clean flux residual

Fig 12A






Flg 126




Deposit diffusion barrier





Deposit second kind of solder paste



Reflow wafer to form solder bump Clean flux residual